

Follow these five basic steps to install the REALITY™ LED downlight and begin enjoying maintenance-free illumination.



Step 1:
Screw in the socket adapter just like you would install a standard incandescent lamp.



Step 4:
Compress the springs on the side of the downlight and insert them into the brackets on the inside of the pre-installed recessed housing.



Step 2:
Remove one of the screws from the existing housing and place the ring terminal from the green bonding wire under the screw and retighten the screw to the housing. Plug the male end of the socket adapter into the female end that is attached to the downlight.



Step 5:
Gently press upward until the downlight is snug against the ceiling.



Step 3:
Secure the socket assembly to the top of the downlight by pressing the sides of the black springs and inserting them into the notches on the top of the bracket.

