Bussmann®

TRON[®] In-Line Fuseholders Double-Pole for Class CC and ${}^{13}_{32}$ " × 1½" Fuses

HEX & HEY Series



HEX Series

Catalog Symbol: HEX-AA^{(1) (2)}, HEX-AB, HEX-AC, HEX-AD, HEX-AE, HEX-AY, HEX-BB, HEX-CC, HEX-JJ, HEX-JK, and HEX-KK.

In-Line Fuseholders, Double Pole Water-Resistant

For breakaway holders, see page 2

Agency Information:

⁽¹⁾UL Recognized, Guide IZLT2, File E14853 ⁽²⁾CSA Certified, Class 6225-01, File 47235

HEX — For any $\frac{13}{32}$ " × $1\frac{1}{2}$ " fuse. Fuseholder rated 30A, 600V (CSA Listed 15A max.). Typical fuse types: BAF, FNM, FNQ, and KTK ($\frac{1}{10}$ - 30A).



HEY Series Catalog Symbol: HEY-AA, HEY-AB, HEY-AC, HEY-AD, HEY-AE, HEY-AL, HEY-BB, and HEY-JJ. In-Line Fuseholders, Double-Pole Water-Resistant

For breakaway holders, see page 2

HEY — Optional breakaway receptacle, water-resistant, polarized, and accepting Class CC branch circuit fuses (Buss Type KTK-R, FNQ-R, & LP-CC; 600V or less, 200,000A interrupting rating.) Particularly applicable in street lighting circuits. **Example:**

A double-pole, in-line holder for Class CC fuses. A single #12 stranded copper wire, copper crimp, on the load side. A single #4 stranded, copper wire, copper crimp on the line side. Insulating boots are required.

- 1. Choose HEY- Series.
- 2. Choose "A" for load side.
- 3. Choose "C" for line side.
- 4. Choose 2A0660 insulating boots from page 2.

Complete Catalog Number: HEY-AC, 2A0660; 4 insulating boots required per holder

Recommended Torque on Coupling Nut: 10-20 in-lb.

Catalog and Speci	fication Data					
Conductor Terminals Conductor Data					Catalog	
Terminal Type	Size	Size _		led	Symbol	
		No. Per Termina	Solid	Stranded		
Copper Crimp	#12 to #8	1	•	•	- A	
	#12	2	•	•	7.	
	#10	2	•	•		
	#6 #4	1	•	•	B	
	#4	1	•	•		
	#8	1	•	•	- C	
	#4 #6	2	-			
	#2	1		•	- D	
	#4	2	•	•	E	
	#12 to #3	2	•	•	У	
Aluminum Set-Screw						
	#12 to #2	1	•	•	L	
	#12 to #2	2	•	•	Υ	
Catalog Data — Ins	ulating Boots	5				
		Catalog Numbers		Туре		
and the second s	2A0660	2A0660		Single Conductor		
Statistics of the local division of the	2A0661	2A0661		Two Conductor		

General Information:

- Insulating boots are **not** included with **non-breakaway** parts and must be ordered separately. They come standard with the breakaway series. The HEX-AW does not have the boots. This catalog item does not have a breakaway receptacle.
- When boots are utilized, extra heat retention requires that fuses are sized at a minimum of 200% of the RMS load current.

Ordering Information:



