## INSTALLATION INSTRUCTION

## **LEDme® Button Lights**

HR-LED85

# WAC LIGHTING Responsible Lighting®

## **CAUTION:**

#### TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK AND INJURIES TO PERSONS:

- Use only insulated staples or plastic ties to secure cords.
- Route and secure cords so they will not be pinched or damaged when cabinet is pushed to the wall.
- Not intended for recessed installation in ceilings.
- Use only with WAC Class 2 LED Power supplies.

#### **RECESS MOUNT**


- 1. Cut a 2 1/8" diameter hole on the surface.
- 2. The decorative cover piece is not needed for recessed mounting, and may be discarded.
- 3. Feed the fixture wires through the hole, and connect to wires from the Power Supply with connector.
- 4. Compress the springs on either side of the fixture and insert into the opening.

## **SURFACE MOUNT**


- Wires may be run behind the fixture or along a surface.
   Determine the most convenient location for wire passage.
   The "D" shaped knock out hole in the cover piece allows wire to exit and run along a surface.
  - To wire behind the fixture, drill a hole in the surface sufficient to allow the socket wires through. Punch the knock out in the cover piece and align with the hole.
- Screw the cover piece to the surface with screws provided.
- 3. Feed the fixture wires through the hole, and connect to wires from the power supply with connector.
- 4. Compress the springs on either side of the fixture and insert into the back cover.

#### **POWER SUPPLY WIRING:**


Cabinet fixtures require WAC power supply. Primary wires to the power supply enclosure must follow normal NEC chapter 3 wiring techniques.



#### Recess mount



#### Surface mount



## \*\*\* PLEASE REFER TO WIRING DIAGRAM SUPPLIED WITH LED POWER SUPPLY